

SANITARY HAND WASH STATION

AS A RESULT OF THE OUTBREAK OF THE CORONAVIRUS, BUSINESSES THAT ARE STILL ABLE TO FUNCTION, ARE REQUIRED TO PROVIDE SANITARY HAND WASHING FACILITIES AMONGST OTHER PERSONAL HYGIENE AND PPE REQUIREMENTS. HOWEVER, THERE MAY BE WORK AREAS THAT DO NOT HAVE ACCESS TO A PLUMBED WATER SUPPLY, TO PROVIDE SUITABLE HAND WASHING FACILITIES.

PLEASE NOTE – BEFORE USING HANDWASH UNIT SIMPLY REMOVE THE 4 SCREWS SUPPORTING EYEWASH SIGN AND REPLACE THE EYEWASH SIGN WITH THE INCLUDED HANDWASH OPERATING SIGN. ALSO REMOVE THE STICKER/S ON THE FRONT LEFT FOR MODEL SE5000 AND FRONT LEFT AND RIGHT OF MODEL SE5050.

Pratt Safety are offering two Self Contained Hand Wash Stations that can provide a limited supply of water which can be used for washing of hands. It is permissible to wash hands with a soapy solution and water where alcohol-based hand washes are not available.

Both Hand Wash Stations can provide a low water flow rate for up to 15 minutes. They can be wall mounted or mounted onto a portable table or similar.

Both models are activated by a pull-down tray and turned off by pushing the tray upwards back into its original position.

Model **SE5000H** has a water capacity of 35L and is best suited to an outdoor location as there is no water catchment tray. It is possible to fit a bucket or bin underneath to catch the water if required.

Model **SE5050H** has a water capacity of 55L with 35L of usable water storage. However, this unit has a catchment tray with a drainage hose to catch the waste-water, making it suitable for indoor applications.

In addition to the Hand Wash Station, a hand wash soapy solution dispenser and disposable paper towels will be required. These items can be provided by your safety supplier.

Please note these stations must **NOT** be used as an Eyewash. Recommended wash time is minimum of 20 seconds.

Either model Hand Wash Station will require regular monitoring to ensure the water level is replenished as deemed appropriate for the work area and usage.



SE5000H



SE5050H