

CLASS 4 DANGEROUS GOODS STORAGE CABINET - 30LTR, 1 DOOR, 1 SHELF
PRODUCT CODE: 5516AC4

Pratt Indoor Class 4 Storage Cabinets comply with the new Standard AS/NZS 5026 “The Storage and Handling of Class 4 Dangerous Goods”.

This range of cabinets is for the storage of Class 4 chemicals in liquid or solid form as classified by the United Nations criteria and the ADG Code for Dangerous Goods. Please refer to the Standard. These include the following divisions: Flammable Solids, Spontaneously Combustible, and Dangerous When Wet.

FEATURES AND BENEFITS:

- Low profile under bench design.
- Constructed of double walled 1.2mm thick galvanised steel.
- 1 x 1.6mm thick, perforated, galvanised steel shelf.
- Continual piano type door hinge.
- Overlapping door edging to prevent ingress of heat.
- Adjustable shelf heights at 45mm increments.
- 2 x 50mm vent bungs with steel caps.
- Each vent incorporates steel flash arrester.
- Single self closing door with speed adjustable hydraulic closure.
- Magnetic catch to hold door in closed position to provide automatic release in the event of pressure build up.
- Recessed non lockable handle.
- External static earthing connection and 1 x bonding wire.
- Solvent resistant yellow baked powder coated finish.
- 150mm deep liquid tight sump.
- Palletized and packaged with strong cardboard carton for protection during transportation and storage.
- Either – Flammable Solid, Spontaneously Combustible or Dangerous When Wet diamonds and other decals applied.
- Optional additional shelves available.



Weight: 53kg
Capacity: 30L
Doors: 1
Shelves: 1 (Inc. Base Level)
Extra Shelf: 5517-29S



EXTERNAL (mm)			INTERNAL (mm)		
HEIGHT	WIDTH	DEPTH	HEIGHT	WIDTH	DEPTH
770	515	465	525	420	370

* AS/NZS 5026 specifies a maximum of 25kg or L for Category A, 50kg or L of Category B or 100kg or L of Category C, Class 4 Chemicals. Other capacity limitations do apply. Refer to the Standard for further details.

Note: 1. Internal height is taken from the top of the sump sill/bottom shelf to the ceiling.
2. For total external width measurement, add 6mm per vent bung for tight clearance locations.

VOLUME CAPACITY	PER SHELF	TOTAL
2L Winchester	6	6
4L Winchester	4	4
4L Paint Can	4	4
10L Paint Can	2	2
15L Paint Can	1	1
20L Paint Can	1	1
Aerosol Can	30	30