

TOXIC SUBSTANCE STORAGE CABINET - 100LTR, 2 DOORS, 1 SHELF

PRODUCT CODE: 5535AST

Pratt Indoor Toxic Substance Storage Cabinets comply with the Australian and New Zealand Standard AS/NZS 4452 "The Storage and Handling of Toxic Substances".

This range of cabinets is for the storage of toxic substances in liquid or solid form as classified by the United Nations criteria and the ADG Code for Dangerous Goods. These include chemicals such as Alkaloids, Arsenic, Aniline, Cyanides, Mercury, Phenol - Solid and Trichloroethylene.

FEATURES AND BENEFITS:

- Low profile under bench design.
- Constructed of double walled 1.2mm thick galvanised steel.
- 2 x self closing doors with sequential mechanism.
- 1 x 1.6mm thick, perforated, galvanised steel shelf.
- Continual piano type door hinges.
- Overlapping door edging to prevent ingress of heat.
- Adjustable shelf heights at 45mm increments.
- 2 x 50mm vent bungs with steel caps.
- Each vent incorporates steel flash arrester.
- Doors fitted with speed adjustable hydraulic closures.
- 3 point self latching door mechanism.
- Recessed handle with keyed alike lock with 2 keys.
- External static earth connection & 1 x bonding wire.
- Solvent resistant yellow baked powder coated finish.
- 150mm deep liquid tight sump.
- Palletized and packaged with strong cardboard carton for protection during transportation and storage.
- Toxic Substance diamond and other decals applied.
- Optional additional shelves available.



Weight: 100kg
Capacity: 100L
Doors: 2
Shelves: 1 (Inc. Base Level)
Extra Shelf: 5535-29S



| EXTERNAL (mm) | | | INTERNAL (mm) | | |
|---------------|-------|-------|---------------|-------|-------|
| HEIGHT | WIDTH | DEPTH | HEIGHT | WIDTH | DEPTH |
| 770 | 935 | 620 | 495 | 840 | 530 |

* AS/NZS 4452 specifies a maximum of 25kg or L for Packaging Group I and 50kg or L for Packaging Group II Toxic Substances.

- Note:**
1. Internal height is taken from the top of the sump sill/bottom shelf to the ceiling.
 2. For total external width measurement, add 6mm per vent bung for tight clearance locations.

| VOLUME CAPACITY | PER SHELF | TOTAL |
|-----------------|-----------|-------|
| 2L Winchester | 18 | 18 |
| 4L Winchester | 15 | 15 |
| 4L Paint Can | 12 | 12 |
| 10L Paint Can | 6 | 6 |
| 15L Paint Can | 4 | 4 |
| 20L Paint Can | 4 | 4 |
| Aerosol Can | 91 | 91 |